



# KNOX WIDESPREAD FAUCET INSTALLATION

## BEFORE YOU BEGIN

We recommend consulting a professional if you are unfamiliar with installing plumbing fixtures. Signature Hardware accepts no liability for any damage to the faucet, plumbing, sink, counter top, or for personal injury during installation.

Observe all local plumbing and building codes.

Unpack and inspect the faucet for damage. If any damage is found, contact our Customer Relations team at 1-866-855-2284.

## GETTING STARTED

- Ensure that you have gathered all the required materials that are needed for the installation.
- For these instructions, it is assumed that the old faucet has been completely removed and any necessary repairs or modifications to the water supply have been completed.


## TOOLS AND MATERIALS:

- |   |   |   |
|---|---|---|
|  |  |  |
| Plumbers Tape   | Thread Sealant  | Phillips Screwdriver  |
|  |  |  |
| Adjustable Wrench   | Small Bucket  | Basin Wrench  |


## INSTALLATION

1. Ensure that the water supply below your sink is completely shut off by turning the shutoff valves all the way to the right.

**Tip:** Place a small bucket below your workspace to catch any water that may drip during the installation process.




2. Remove the protective sleeve, lock nut, rubber washer, and metal washer from the faucet spout. Insert the spout into the center faucet hole.






# KNOX WIDESPREAD FAUCET INSTALLATION


3. From under the counter, slide the rubber gasket back onto the spout body followed by the metal washer, and secure using the lock nut. Hand tighten the lock nut, then use a Phillip's screwdriver to tighten the two screws attached to the lock nut.




4. Thread the T-connector onto the end of the spout's threaded shank. Apply plumber's tape to the threads before attaching so that the T-connector can be properly aligned.



5. Remove the handle assembly from the handle valve labeled 'cold,' as shown below. Move the lock nut, metal washer, and rubber washer to their furthest point at the base of the stem. From below, insert the valve stem into the faucet hole on the right.




6. From above the counter, reassemble the handle assembly onto the valve stem. Below the counter, insert the copper supply tube on the T-connector into the side of the valve stem, then tighten the the nut to secure.






# KNOX WIDESPREAD FAUCET INSTALLATION


7. Secure the valve stem to the surface by hand-tightening the lock nut from below. Finish by tightening the two screws located on the lock nut with a Phillip's screwdriver.




8. Repeat steps 5 through 7 for installing the 'hot' handle valve into the left faucet hole.



9. Attach the main water lines to the proper inlet of each valve stem. Use an adjustable wrench to tighten, but be careful not to overtighten. Apply thread sealant or plumber's tape to each threaded connection. Ensure that you are connecting the hot and cold lines appropriately.



10. Proceed to sink drain installation. Once completed, turn the faucet on for approximately 60 seconds. Check for any leaks. Test both hot and cold water to ensure they are running properly.







# KNOX WIDESPREAD FAUCET INSTALLATION

## DRAIN INSTALLATION


1. Dissassemble the drain assembly and lay the parts aside, in the same order they were removed. See the illustration below as a reference if needed.



2. Apply plumber's tape to the threading on the tailpiece, then reattach the tail piece to the pop-up drain flange.




3. Slide the flat rubber gasket up the tailpiece until it meets the lip of the pop-up drain flange.






# KNOX WIDESPREAD FAUCET INSTALLATION

4. Insert the drain flange and tailpiece through the top of your sink's drain hole.



5. From under your counter, slide the tapered rubber gasket followed by the plastic friction washer onto the tailpiece until they meet your sink or countertop. Be sure that the tapered side of the rubber washer is facing up.



6. Thread the lock nut onto the drain flange. Hand tighten until secure, then finish tightening with a basin wrench once the drain is properly aligned.

**Important:** Be careful not to overtighten, which could crack a porcelain sink or stone countertop.

